SUCY Torque Screwdriver





Steps to Find Your Torque Screwdriver

This guide is designed to help you finding a selection of tools that may best fit your application.



1 Adapter

Identify the torque range you need to apply

Adapter range: 0.1Nm~18.0Nm

1700 00 Nm 000 N

"Click" sound to let you know the torque is reached.

The Sloky torque screwdriver is set to a specific torque value when force is applied the screwdriver will create a "click" sound and feel when it reaches the set torque value. Stop applying force at click to avoid over tightening.

2 Handle

Choose the most suitable handle

Ergonomic design



Three types of handles for your choice!

The soft zone is comfortable to hold and easy to tighten and loosen screws even in highere torque range.

Ergonomic rubber hand grip is to prevent hand injuries such as blisters and calluses.

Handle	Torque range
Slim-Fit	0.6~2.0Nm
Universal	0.6~5.5Nm
T-Flying	3.0~10.0Nm

3 Bits

Find out what kinds of bits are best work for you

Color Identity



No mistake!

The color identification is visible on both adapters and bits.

Select suitable torque size by color management system indicated on torque adapters and bits. It is to enhance the covenience of using and delivery proper tightening torque.

Bits length are available for 25mm, 50mm & 75mm

and more ...





